

ULANO GHOST REMOVER ADVANCE

Viscous cleaning agent for the removal of ghost images and mesh colourations

ULANO GHOST REMOVER ADVANCE is used for the removal of ghost images and mesh colourations. **ULANO GHOST REMOVER ADVANCE** can unrestrictedly be used on polyester meshes, do not exceed a reaction time of 1 hour on nylon or V2A meshes. When using V2A meshes its application can further be restricted due to varying qualities or pre-damages caused by other chemicals. Trials are essential. **ULANO GHOST REMOVER ADVANCE** is not suitable for metallized (nickel-plated) polyester mesh.

PROPERTIES

ULANO GHOST REMOVER ADVANCE quickly and safely removes ghost images and mesh colourations, especially those caused by Diazo sensitizers. Additional ink residue can be removed with solvents after treatment with **ULANO GHOST REMOVER ADVANCE**. Do not remove photoemulsion residue with **ULANO GHOST REMOVER ADVANCE**. A mixture of alkaline pastes and solvent cleaners or **ULANO ACTIGHOST RAPID GEL** is more effective. Ask your distributor for advice.

The viscosity of **ULANO GHOST REMOVER ADVANCE** allows a perfect coating on coarser mesh. Even after a longer reaction time, sufficient **ULANO GHOST REMOVER ADVANCE** remains on the mesh.

APPLICATION

Apply **ULANO GHOST REMOVER ADVANCE** with a V2A (stainless steel) coating trough onto both sides of the decoated and dried screen. Residue in the coating trough should be disposed of as **ULANO GHOST REMOVER ADVANCE** quickly absorbs contamination from the mesh which reduces the active components in the original container.

The standard reaction time should be at least 6 hours. Within this period the chloric active component is decomposed and no activated chlorine gets into the waste water while rinsing. We recommend a reaction time overnight (at approx. 20-23°C) as the working process is then disturbed least.

Notice: When applying **ULANO GHOST REMOVER ADVANCE** onto mechanically damaged or often decoated meshes, especially fine mesh may tear. However, this cleaning method is often the only possibility to reclaim the mesh. It is therefore recommended to test the suitability of the cleaner for specific applications beforehand, as any responsibility for torn screen mesh cannot be assumed.

Notice: Depending on the mesh brand and the reaction time, **ULANO GHOST REMOVER ADVANCE** may bleach dyed meshes.

PRODUCT DATA	Colour:	yellow, clear
	Consistency:	viscous
	pH-value:	approx. 13

HEALTH HAZARDS/ ENVIRONMENTAL PROTECTION	When working with ULANO GHOST REMOVER ADVANCE it is recommended wearing suitable safety goggles, rubber apron and rubber gloves. Avoid contact with acids or acidic products (e.g. decoating products).
---	--

This data sheet is for your information. A legally binding assurance of the product's suitability for a specific purpose cannot be derived from it and no liability can be assumed for any potential damages that may occur. Our products are subject to continuous production and quality control and leave our company in perfect condition.

This product is intended solely for industrial applications and not for use by the end consumer. We recommend to our customers to always test the product themselves since only in this way – also after production – can the freedom from certain substances and the suitability for a particular purpose be verified. The user has to test the product for suitability for the intended application. We reserve the right to modify product specifications. Tests that are not part of the specifications of the product mentioned above have not been carried out.

All information applies only to the above-mentioned product obtained from Kissel + Wolf GmbH. It corresponds to our current state of knowledge, but is not a confirmation of a particular application and is not automatically replenished. All information is valid for a maximum of 12 months (annexes may be provided with their own date) or until legal changes are made in this time period. The recipient of our product is solely responsible for observing any possible property rights as well as existing laws and regulations. Property rights of third parties must be observed. Our terms and conditions of sale and delivery shall apply.

Please follow further information given in the material safety data sheet. Due to the oxidizing effect of **ULANO GHOST REMOVER ADVANCE**, AOX-Value-Determinations according to DIN EN ISO 9562 may be influenced.

STORAGE

1 year (at 20 - 25°C and in original container). Keep out of sun, store in a cool place.

From about - 5°C on **ULANO GHOST REMOVER ADVANCE** becomes milky, after warming up to room temperature the solution becomes clear again.